



**Installation / Operation / Maintenance  
Manual**

**CHEMGUARD GenIII 110-  
410**

**Chemical Equipment**

**Manual Part Number: 477441**

**Edition: Rev-11 12/01/2020**

The information and data contained herein are proprietary to Versum Materials, Inc. and are not to be copied, reproduced, duplicated, or disclosed to others, in whole or in part, without prior written consent of Versum Materials, Inc. The information and data should be available only to those with a need to know. Versum Materials, Inc. makes no representation that the information and data is appropriate for the recipient, and each recipient needs to independently evaluate the appropriateness of the information and data for its use.

This Installation and Operation Manual is subject to change without notification. For current technical information please call Product Support at (866)624-7677 from continental U.S., or write Versum Materials, Inc., 1919 Vultee Street, Allentown, PA 18103, attention: Product Support.

Printed in the U.S.A.

## **WARRANTY**

Versum Materials, Inc. (hereinafter referred to as "Versum Materials") warrants that:

(A) Each new Versum Materials Delivery System is free from defects in material and workmanship under normal use and service for a period of one year from the date of delivery by Versum Materials to the first purchaser.

(B) Each new accessory is free from defects in material and workmanship under normal use and service for a period of one (1) year from the date of delivery by Versum Materials to the first purchaser.

If any product requires service during the applicable warranty period, the purchaser should communicate directly with Versum Materials to determine appropriate repair. Repair or replacement will be carried out at Versum Materials expense subject to the terms of this warranty. It is the responsibility of the customer to perform routine maintenance and periodic calibration.

In no event shall Versum Materials be liable for any incidental, indirect or consequential damages in connection with the purchase or use of any Versum Materials product. This warranty shall not apply to, and Versum Materials shall not be responsible for, any loss arising in connection with the purchase or use of any Versum Materials product which has been repaired by anyone other than an authorized Versum Materials service representative or altered in any way so as, in Versum Materials judgment, to affect its stability or reliability, or which has been subject to misuse or negligence or accident, or which has the unit or lot number altered, effaced or removed, or which has been used otherwise than in accordance with the instructions furnished by Versum Materials. This warranty is in lieu of all other warranties, express or implied, and all other obligations or liabilities on Versum Materials part, and Versum Materials neither assumes nor authorizes any representative or other person to assume for it any other liability in connection with the sale of Versum Materials equipment.

**VERSUM MATERIALS DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR APPLICATION.**

Address:

Versum Materials, Inc.  
1919 Vultee Street  
Allentown, PA 18103, U.S.A

## Revision Control Summary

Chapter	Revision	File Name
<b>Chapter 1 – Delivery and Inspection</b>		
• Initial Release	Rev-0	MNL000494.doc
<b>Chapter 2 – Site Preparation</b>		
• Added 8x outlet manifold	Rev-6	MNL000495.doc
<b>Chapter 3 – Installation</b>		
• Updated DO connection points for 8x outlets	Rev-5	MNL000496.doc
<b>Chapter 4 – Changing Reservoir Container</b>		
• Initial Release	Rev-0	MNL000497.doc
<b>Chapter 5 – Features and Components</b>		
• Updated spill funnel model types	Rev-5	MNL000498.doc
<b>Chapter 6 – System Operation</b>		
• Initial Release	Rev-0	MNL000499.doc
<b>Chapter 7 – Maintenance and Calibration Procedure</b>		
• Removed CG410NT reference.	Rev-2	MNL000500.doc
<b>Appendix G – Models SS2 &amp; SS4 Fire Detector</b>		
• Initial Release	Rev-3	MNL000115.doc
<b>Appendix H – Smoke Detector</b>		
• Initial Release	Rev-3	MNL000116.doc
<b>Addendum D – High Flow Degasser</b>		
• Initial Release	Rev-4	MNL000187.doc
<b>Addendum F – CG Bulk Container Fit-up Envelope</b>		
	Rev-4	MNL000292.doc

- Removed CG410NT reference.

**Addendum Y – UVIR Detector**

Rev-6

MNL000114.doc

- Initial Release

# TABLE OF CONTENTS

<b>Chapter 1</b>	<b>Delivery and Inspection</b>	
	Section 1 Delivery .....	1-2
	Section 2 Inspection .....	1-3
<b>Chapter 2</b>	<b>Site Preparation</b>	
	Section 1 Facility Preparation .....	2-3
	Section 2 Facility Requirements .....	2-5
	Section 3 Tag and Lockout Routine .....	2-21
	Section 4 Spill Cleanup Routine .....	2-22
<b>Chapter 3</b>	<b>Installation</b>	
	Section 1 Introduction .....	3-4
	Section 2 Reference Documents .....	3-5
	Section 3 Installation .....	3-6
	Section 4 Installing the ChemGuard® Cabinet .....	3-8
	Section 5 Connecting ChemGuard® Gas Lines .....	3-14
	Section 6 Installing ChemGuard® Bulk Scale .....	3-21
	Section 7 ChemGuard® Communications .....	3-22
	Section 8 ChemGuard® Start-up and Initialization .....	3-33
	Section 9 ChemGuard® System Configuration .....	3-38
	Section 10 Manual Mode .....	3-40
	Section 11 Pressure Regulator Adjustment .....	3-44
	Section 12 System Leak Check .....	3-45
	Section 13 System Leak Check – External Refill Option .....	3-47
	Section 14 System Leak Check – AMAT Degasser Option .....	3-49
	Section 15 Installing Optional Refillable Bulk Container .....	3-52
	Section 16 Finishing the ChemGuard® Installation .....	3-56
<b>Chapter 4</b>	<b>Changing Reservoir Container</b>	
	Section 1 Safety Notes .....	4-3
	Section 2 Removing and Replacing the Reservoir Containers .....	4-4
	Section 3 Change BULK Container Operation .....	4-5
<b>Chapter 5</b>	<b>Features and Components</b>	
	Section 1 Overview .....	5-2
	Section 2 Component Description .....	5-4
	Section 3 Available Options .....	5-9
<b>Chapter 6</b>	<b>System Operation</b>	
	Section 1 Theory of Operation .....	6-3
	Section 2 Description of Menus and Operations .....	6-5
	Section 3 Operating Menu .....	6-6
	Section 4 Alarm Types .....	6-19

<b>Chapter 7</b>	<b>Maintenance and Calibration Procedure</b>	
	Section 1 Introduction .....	7-3
	Section 2 Calibration and Testing .....	7-4
<b>Appendix G</b>	<b>Models SS2 &amp; SS4 Fire Detectors</b>	
<b>Appendix H</b>	<b>Smoke Detector</b>	
<b>Addendum D</b>	<b>High Flow Degasser</b>	
<b>Addendum F</b>	<b>CG Bulk Container Fit-up Envelope</b>	
<b>Addendum Y</b>	<b>UVIR Detector</b>	