



**GEN II ChemGuard™ CG100-325,  
CG400NT Chemical Delivery  
System  
Installation and Operation Manual**

Ordering information:

P/N 143936

REV. G

Standard Paper Copy



The information and data contained herein are proprietary to Versum Materials, Inc. and are not to be copied, reproduced, duplicated, or disclosed to others, in whole or in part, without prior written consent of Versum Materials, Inc. The information and data should be available only to those with a need to know. Versum Materials, Inc. makes no representation that the information and data is appropriate for the recipient, and each recipient needs to independently evaluate the appropriateness of the information and data for its use.

This Installation and Operation Manual is subject to change without notification. For current technical information please call Product Support at (800) 545-9242 from continental U.S., or write Versum Materials, Inc., 7201 Hamilton Blvd, Allentown, PA 18195, attention: Product Support.

© 2006 -- 2015 Versum Materials, Inc. All rights reserved

Printed in the U.S.A.





## WARRANTY

Versum Materials, Inc. (hereinafter referred to as "Versum Materials, Inc.") warrants that:

(A) Each new Versum Materials, Inc. GEN IIB ChemGuard™ Chemical Delivery System is free from defects in material and workmanship under normal use and service for a period of one year from the date of delivery by Versum Materials, Inc. to the first purchaser.

(B) Each new accessory is free from defects in material and workmanship under normal use and service for a period of one (1) year from the date of delivery by Versum Materials, Inc. to the first purchaser.

If any product requires service during the applicable warranty period, the purchaser should communicate directly with Versum Materials, Inc. to determine appropriate repair. Repair or replacement will be carried out at Versum Materials, Inc. expense subject to the terms of this warranty. It is the responsibility of the customer to perform routine maintenance and periodic calibration.

This warranty is expressly conditioned on compliance with Versum Materials, Inc. operating instructions and the use of the equipment only for authorized chemicals. Operation of the equipment other than as set forth in Versum Materials, Inc. operating instructions or the use of the equipment for unauthorized chemicals shall void all of Versum Materials, Inc. warranties hereunder.

In no event shall Versum Materials, Inc. be liable for any incidental, indirect or consequential damages in connection with the purchase or use of any Versum Materials, Inc. equipment. This warranty shall not apply to, and Versum Materials, Inc. shall not be responsible for, any loss arising in connection with the purchase or use of any Versum Materials, Inc. equipment which has been repaired by anyone other than an authorized Versum Materials, Inc. service representative or altered in any way so as, in Versum Materials, Inc. judgment, to affect its stability or reliability, or which has been subject to misuse or negligence or accident, or which has the unit or lot number altered, effaced or removed, or which has been used otherwise than in accordance with the instructions furnished by Versum Materials, Inc..

This warranty is in lieu of all other warranties, express or implied, and all other obligations or liabilities on Versum Materials, Inc. part, and Versum Materials, Inc. neither assumes nor authorizes any representative or other person to assume for it any other liability in connection with the sale of Versum Materials, Inc. equipment.

**VERSUM MATERIALS, INC. DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR APPLICATION.**

Corporate address:

Versum Materials, Inc.  
1919 Vultee Street  
Allentown, PA 18195-1501, U.S.A.

### **Revision Control Summary**

<b>Chapter</b>	<b>Revision</b>	<b>Date</b>	<b>File Name</b>
<b>Introduction</b>	Rev-1	September 2016	MNL000404.doc
<b>Chapter 1 – Delivery and Inspection</b>	Rev-1	September 2016	MNL000405.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 2 – Site Preparation</b>	Rev-1	September 2016	MNL000406.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 3 – Installation</b>	Rev-1	September 2016	MNL000407.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 4 – Changing Reservoir Containers</b>	Rev-1	September 2016	MNL000408.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 5 – ChemGuard Features and Components</b>	Rev-1	September 2016	MNL000409.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 6 – System Operation</b>	Rev-1	September 2016	MNL000410.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			
<b>Chapter 7 – Maintenance &amp; Calibration Procedures</b>	Rev-1	September 2016	MNL000411.doc
<ul style="list-style-type: none"> <li>• Updated company name and logo.</li> </ul>			

**Addendum B – Gas Filter Setup**

Rev-1 September 2016 MNL000108.doc

- Updated company name and logo.

**Addendum Y – UVIR Detector**

Rev-5 September 2016 MNL000114.doc

- Updated company name and logo.

**Addendum Z – USB Barcode**

Rev-2 September 2016 MNL000001.doc

- Updated company name and logo.

**Appendix A – Standard Degasser Test Procedure**

Rev-1 September 2016 MNL000412.doc

- Updated company name and logo.

**Appendix B – Network Setup ChemGuard**

Rev-1 September 2016 MNL000109.doc

- Updated company name and logo.

**Appendix C – Spare Parts Lists**

Rev-1 September 2016 MNL000413.doc

- Updated company name and logo.

**Appendix D – Facilities Preparation Checklist**

Rev-1 September 2016 MNL000110.doc

- Updated company name and logo.

**Appendix E – Versum Materials, Inc. GasGuard OPC Server**

Rev-1 September 2016 MNL000111.doc

- Updated company name and logo.

**Appendix F – Gas Sensor Modules**

Rev-1 September 2016 MNL000112.doc

- Updated company name and logo.

**Appendix G – Multi-Spectrum Digital, Electro-Optical Radiant Energy Models  
SS2 & SS4 Fire Detectors**

Rev-2 September 2016 MNL000115.doc

- Updated company name and logo. This file needs to be completed.

**TABLE OF CONTENTS**

Introduction	
I.1	Introduction to the Manual..... I-1
I.2	Notes..... I-2
I.3	Safety Label..... I-4
Chapter 1	Delivery and Inspection
1.1	Delivery..... 1-1
1.2	Inspection..... 1-1
Chapter 2	Site Preparation
2.1	Facility Preparation ..... 2-1
2.1.1	Bolt-down and Ground Cabinet Requirements..... 2-1
2.2	Facility Requirements..... 2-3
2.2.1	Environmental Requirements ..... 2-5
2.2.2	Electrical Requirements ..... 2-5
2.2.3	Process Tool Interface and Life Safety Interconnect ..... 2-5
2.2.4	Supply Gases ..... 2-6
2.2.5	Vacuum Requirements..... 2-8
2.2.6	Vacuum Pump Interlock ..... 2-9
2.2.7	Exhaust And Vent Requirements ..... 2-10
2.2.8	Chemical Delivery Line Requirements ..... 2-11
2.2.9	Installing the Optional Coaxial Chemical Delivery Lines ..... 2-11
2.2.10	Chemical Refill Line (Optional) ..... 2-12
2.2.11	Output Manifold (Optional) ..... 2-12
2.3	Tag and Lockout Routine..... 2-12
2.4	Spill Cleanup Routine ..... 2-12
Chapter 3	Installation
3.1	Introduction..... 3-1
3.2	Installation..... 3-1
3.2.1	Pre-installation ..... 3-1
3.2.2	Available Configurations ..... 3-2
3.3	Installing The ChemGuard Gen II Cabinet ..... 3-3
3.4	Electrical Connections ..... 3-3
3.4.1	Installation..... 3-3
3.4.2	Electrical Requirements ..... 3-3
3.4.3	Connecting Line AC Power ..... 3-5
3.4.4	Connecting Degasser Vacuum Pump (Degasser Option) ..... 3-5
3.4.5	Connecting Inputs/Outputs ..... 3-6
3.5	ChemGuard Gen II I/O Interface with Controller Termination Points (Visual Aid) ..... 3-11
3.6	Connecting ChemGuard Gen II Gas Lines..... 3-21
3.7	Chemical Delivery Line Requirements ..... 3-22
3.7.1	Bulk Reservoir Refill (Optional) ..... 3-22
3.7.2	Bulk Trickle Purge Pigtail (Optional) ..... 3-23
3.8	Installing ChemGuard Gen II Reservoir Scale(s) ..... 3-23
3.8.1	Bulk Scale (optional) Installation ..... 3-23
3.9	Process Tool Interface Connection ..... 3-25
3.10	Installing System Vacuum ..... 3-26
3.10.1	Vacuum Requirements..... 3-26

3.10.2	Multiple ChemGuard Gen IIs Connected To A Vacuum Pump.....	3-26
3.11	Installing System Exhaust and Vent .....	3-26
3.11.1	Exhaust and Vent Requirements.....	3-26
3.11.2	Connecting ChemGuard Gen II Exhaust .....	3-26
3.11.3	Connecting ChemGuard Gen II to Monitoring System.....	3-27
3.12	Initializing the ChemGuard System .....	3-27
3.12.1	System Setup .....	3-27
3.12.2	Source System Configuration .....	3-30
3.13	System Features .....	3-39
3.13.1	Manual Operation .....	3-39
3.13.2	System Test .....	3-41
3.13.3	Valve Setup .....	3-42
3.13.4	Valve Counts .....	3-42
3.13.5	Operation Sequences .....	3-42
3.13.6	Sequence Flow Options.....	3-42
3.13.7	Prompt List .....	3-42
3.13.8	Set Time/Date .....	3-43
3.13.9	Analog Scaling .....	3-43
3.13.10	Setpoints .....	3-43
3.13.11	Alarm Conditions .....	3-43
3.13.12	Alarm Delays .....	3-43
3.13.13	Alarm Types .....	3-44
3.13.14	Alarm Sequences.....	3-44
3.13.15	Relay Defaults .....	3-44
3.13.16	Helium Leak Check .....	3-44
3.13.17	1st Security List .....	3-44
3.13.18	2nd Security List .....	3-44
3.13.19	3rd Security List.....	3-45
3.13.20	2nd Security Access.....	3-45
3.13.21	3rd Security Access.....	3-45
3.13.22	System Setup .....	3-45
3.13.23	Config Transfer .....	3-49
3.13.24	Memory Management .....	3-49
3.13.25	Source System Information.....	3-50
3.14	System Startup .....	3-51
3.14.1	Initial Installation of Process reservoir container .....	3-51
3.14.2	Optional refillable Bulk reservoir container, initial installation .....	3-51
3.14.3	Delivery manifold with optional purge capabilities .....	3-52
3.14.4	Performing leak check of the stainless steel plumbing.....	3-52
3.14.5	Degasser leak check .....	3-54
3.14.6	Pressure regulator adjustment .....	3-55
3.14.7	Install non-refillable Bulk reservoir .....	3-56
3.14.8	Optional refillable Bulk reservoir .....	3-56
3.14.9	Chemical delivery path preparation.....	3-56
3.14.10	Bulk reservoir to Process reservoir initial fills.....	3-56
3.14.11	Process reservoir initial fill to delivery manifold.....	3-57
3.14.12	Delivery line initial fill.....	3-57
Chapter 4	Changing Reservoir Containers	
4.1	Safety Notes .....	4-2



4.2	Removing and Replacing the Reservoir Containers .....	4-3
4.3	Change BULK Reservoir Operation.....	4-4
4.3.1	Changing the BULK Reservoir Container .....	4-4
4.3.2	BULK Reservoir Diagnostics.....	4-7
4.4	Change PROCESS Reservoir Operation.....	4-7
4.4.1	Changing the PROCESS Reservoir Container .....	4-7
4.4.2	PROCESS Reservoir Diagnostics.....	4-12
Chapter 5	ChemGuard Features and Components	
5.1	Overview .....	5-1
5.1.1	Operational Features .....	5-1
5.1.2	Purity Control Features .....	5-1
5.1.3	Safety and Security Features.....	5-1
5.1.4	Installation in Classified Areas .....	5-2
5.2	Component Description .....	5-3
5.2.1	Reservoir Containers .....	5-6
5.3	System Combustible Vapor Detection (Optional) .....	5-10
5.4	Fire (Rate of Rise) Detection .....	5-10
5.5	Fire Suppression System (Optional) .....	5-10
5.6	Degasser (Optional).....	5-11
5.7	Degasser Vacuum Pump (Optional) .....	5-11
5.8	Bulk Reservoir Refill Line (Optional).....	5-11
5.9	Bulk Trickle Purge Pigtail (Optional).....	5-12
5.10	USB Barcode .....	5-12
5.11	Degasser PT 'Pressure Transducer' (Optional).....	5-12
5.12	Only CG400NT; Cabinet Ultraviolet/Infrared (UVIR) Detector.....	5-12
Chapter 6	System Operation	
6.1	Theory of Operation .....	6-1
6.1.1	Overview .....	6-1
6.1.2	Relay Output Circuit .....	6-2
6.1.3	Valves and Solenoid Output Circuit .....	6-2
6.1.4	Contact / Voltage Input Signals .....	6-4
6.1.5	Spill Detection .....	6-4
6.2	Description of Operation and Menus.....	6-6
6.2.1	Display Screen .....	6-6
6.2.2	Controller LED's .....	6-8
6.2.3	Main Menu .....	6-8
6.2.4	Bulk Main Menu Options .....	6-9
6.2.5	Process Main Menu Options .....	6-14
6.3	Alarm Types .....	6-21
6.4	Ready-Reference Procedures for ChemGuard Operation .....	6-23
Chapter 7	Maintenance and Calibration Procedure	
7.1	Introduction .....	7-1
7.2	Calibration And Testing .....	7-1
7.2.1	Sump Spill (Optical) Sensor Verification (Device Option) .....	7-2
7.2.2	Sump Spill (Dual Float) Sensor Verification.....	7-2
7.2.3	Vapor Detector Verify / Calibration (Device Option) .....	7-3
7.2.4	Thermocouple Gauge Setup.....	7-4
7.2.5	Vacuum Transducer Calibration.....	7-5



7.2.6	Scale Calibration.....	7-6
7.2.7	Ultrasonic Clamp-On Sensor .....	7-8
7.2.8	Other Tests .....	7-9
7.2.9	Rate of Rise Fire Detection (Device Option) .....	7-10
7.2.10	Fire Suppression System (Device Option) .....	7-10
7.3	Troubleshooting .....	7-14
7.3.1	Overview .....	7-14
7.3.2	Main Power .....	7-15
Appendix A	Degasser Test Procedures	
Appendix B	Network Setup – Gen II ChemGuard	
Appendix C	Spare Parts Lists	
Appendix D	ChemGuard Facilities Preparation Checklist	
Appendix E	OPC Server Manual	
Appendix F	Vapor Sensor Model 2001-00 Manual	
Appendix G	Q & A UVIR Detection	
Addendum B	Gas Filter Setup	
Addendum Y	UVIR Detector	
Addendum Z	USB Barcode	

## LIST OF TABLES

Table 2-1	Cabinet Clearances	2-1
Table 2-2	Environmental Requirements	2-5
Table 2-3	Electrical Requirements	2-5
Table 2-4	Digital I/O	2-5
Table 2-5	Supply Gases	2-7
Table 2-6	Vacuum Requirements	2-9
Table 2-7	Exhaust and Vacuum Requirements	2-10
Table 2-8	Chemical Delivery Line Requirements	2-11
Table 3-1	Cabinet Connections	3-6
Table 3-2	Tool Interface	3-7
Table 3-3	Tool Interface PLC (Option)	3-10
Table 3-4	Chemical Delivery Line Requirements	3-22
Table 3-5	Connection Verification Checklists	3-27
Table 3-6	Controller LED's	3-30
Table 3-7	Chemical Maximum Fill Values	3-58
Table 4-1	BULK Reservoir Diagnostics	4-7
Table 4-2	PROCESS Reservoir Diagnostics	4-12
Table 5-1	ChemGuard Stainless Steel Reservoir Container Specifications	5-8
Table 5-2	Chemicals Authorized For Use in ChemGuard	5-9
Table 6-1	Digital Alarms	6-25
Table 6-2	Analog alarms	6-29
Table 6-3	Internal Flags	6-34
Table 6-4	Internal Alarms	6-37
Table 6-5	Relay Outputs	6-40
Table 6-6	AP10/ChemGuard Internal Diagnostic Alarm Supplements	6-41
Table 7-1	Inspections Schedule	7-1
Table 7-2	Electrical Troubleshooting Guide	7-15

## Chapter 1 LIST OF FIGURES

Figure 2-1 Earthquake Bolt-Down Pattern With Front Door Clearances	2-2
Figure 2-2 ChemGuard Gen II Cabinet Connections, Top View	2-3
Figure 2-3 ChemGuard Gen II Cabinet Connections, Front View	2-4
Figure 3-1 ChemGuard Gen II BULK Reservoir Scale Installation	3-25
Figure 3-2 ChemGuard Gen II Power Up Screen	3-28
Figure 3-3 ChemGuard Gen II Controller Main Menu	3-29
Figure 3-4 Alarm and Controller Status Boxes	3-29
Figure 3-5 ChemGuard Gen II Plumbing and Valves Schematic	3-59
Figure 5-1 ChemGuard Cabinet External Connections	5-3
Figure 5-2 ChemGuard Electronic Enclosure	5-4
Figure 5-3 Emergency Manual Off (EMO)	5-5
Figure 5-4 ChemGuard Gen II Display Screen	5-6
Figure 5-5 Typical ChemGuard Stainless Steel Reservoir Container	5-7
Figure 6-1 Spill Sense Probe	6-4
Figure 6-2 Sump Spill (Dual Float Sensors)	6-5
Figure 6-3 ChemGuard GEN II Controller Power Up Screen with Bulk Refill Option	6-6
Figure 6-4 ChemGuard GEN II Controller Power Up Screen with Trickle Purge Option	6-7
Figure 6-5 Alarm and Controller Status Boxes	6-7
Figure 7-1 System Interconnect Diagram	7-19



This Page Intentionally Left Blank