

FORMULATION EXAMPLE

MC-ES-190927B_C Eye Shadow - Blue (Dazzling Light Demo Tool)

Ingredients

Parateck® LUB Talc
RonaFlair® Mica M
 Magnesium Stearate
 Performalene 400 Polyethylene
RonaFlair® Boroneide® SF-15
RonaFlair® Soft Sphere
 Myritol 318
 Xiameter® PMX-200 Silicone Fluid (100cs)
Timiron® Glam Silver
Ronastar® Dazzling Lights
Colorona® Dark Blue

INCI (US)

	[%]
(1) TALC	20.00
(1) MICA	13.00
(2) MAGNESIUM STEARATE	5.00
(3) POLYETHYLENE	2.00
(1) BORON NITRIDE	2.00
(1) SYNTHETIC FLUORPHLOGOPITE (AND) SILICA	2.00
(4) CAPRYLIC/CAPRIC TRIGLYCERIDE	10.00
(5) DIMETHICONE	2.00
(1) ALUMINA (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	4.00
(1) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	20.00
(1) MICA (AND) TITANIUM DIOXIDE (AND) FERRIC FERROCYANIDE	20.00

Procedure:

1. Mix base with other pigments and filler and binder till uniform
2. Fill in mould and stamp to certain shape

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- | | |
|--|--------------------------------|
| (1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials | (2) Whittaker, Clark & Daniels |
| (3) New Phase Technologies | (4) BASF AG |
| (5) Biesterfeld | |

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parateck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.

FORMULATION EXAMPLE

MC-ES-190927C_C Eye Shadow - Green (Dazzling Light Demo Tool)

Ingredients

Parateck® LUB Talc
RonaFlair® Mica M
 Magnesium Stearate
 Performalene 400 Polyethylene
RonaFlair® Boroneide® SF-15
RonaFlair® Soft Sphere
 Myritol 318
 Xiameter® PMX-200 Silicone Fluid (100cs)
Timiron® Glam Silver
Timiron® Splendid Green
Ronastar® Dazzling Lights
Colorona® Patina Gold

INCI (US)

	[%]
(1) TALC	20.00
(1) MICA	13.00
(2) MAGNESIUM STEARATE	5.00
(3) POLYETHYLENE	2.00
(1) BORON NITRIDE	2.00
(1) SYNTHETIC FLUORPHLOGOPITE (AND) SILICA	2.00
(4) CAPRYLIC/CAPRIC TRIGLYCERIDE	10.00
(5) DIMETHICONE	2.00
(1) ALUMINA (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	4.00
(1) TITANIUM DIOXIDE (AND) MICA (AND) SILICA	24.00
(1) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	12.00
(1) MICA (AND) TITANIUM DIOXIDE (AND) IRON OXIDES (AND) IRON OXIDES	4.00

Procedure:

1. Mix base with other pigments and filler and binder till uniform
2. Fill in mould and stamp to certain shape

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- | | |
|--|--------------------------------|
| (1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials | (2) Whittaker, Clark & Daniels |
| (3) New Phase Technologies | (4) BASF AG |
| (5) Biesterfeld | |

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parateck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emlibcain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.

FORMULATION EXAMPLE

MC-ES-190927D_C Eye Shadow - yellow (Dazzling Light Demo Tool)

Ingredients

Parateck® LUB Talc
RonaFlair® Mica M
 Magnesium Stearate
 Performalene 400 Polyethylene
RonaFlair® Boroneide® SF-15
RonaFlair® Soft Sphere
 Myritol 318
 Xiameter® PMX-200 Silicone Fluid (100cs)
Timiron® Glam Silver
Ronastar® Dazzling Lights
Colorona® Imperial Citrine

INCI (US)

	[%]
(1) TALC	20.00
(1) MICA	13.00
(2) MAGNESIUM STEARATE	5.00
(3) POLYETHYLENE	2.00
(1) BORON NITRIDE	2.00
(1) SYNTHETIC FLUORPHLOGOPITE (AND) SILICA	2.00
(4) CAPRYLIC/CAPRIC TRIGLYCERIDE	10.00
(5) DIMETHICONE	2.00
(1) ALUMINA (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	4.00
(1) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	20.00
(1) MICA (AND) BISMUTH OXYCHLORIDE (AND) IRON OXIDES	20.00

Procedure:

1. Mix base with other pigments and filler and binder till uniform
2. Fill in mould and stamp to certain shape

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- | | |
|--|--------------------------------|
| (1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials | (2) Whittaker, Clark & Daniels |
| (3) New Phase Technologies | (4) BASF AG |
| (5) Biesterfeld | |

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parateck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.

FORMULATION EXAMPLE

MC-ES-190927A_C Eye Shadow - Brown (Dazzling Light Demo Tool)

Ingredients

Parateck® LUB Talc
RonaFlair® Mica M
 Magnesium Stearate
 Performalene 400 Polyethylene
RonaFlair® Boroneide® SF-15
RonaFlair® Soft Sphere
 Myritol 318
 Xiameter® PMX-200 Silicone Fluid (100cs)
Timiron® Glam Silver
Ronastar® Dazzling Lights
Colorona® Aborigine Amber

INCI (US)

	[%]
(1) TALC	20.00
(1) MICA	13.00
(2) MAGNESIUM STEARATE	5.00
(3) POLYETHYLENE	2.00
(1) BORON NITRIDE	2.00
(1) SYNTHETIC FLUORPHLOGOPITE (AND) SILICA	2.00
(4) CAPRYLIC/CAPRIC TRIGLYCERIDE	10.00
(5) DIMETHICONE	2.00
(1) ALUMINA (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	4.00
(1) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	20.00
(1) MICA (AND) IRON OXIDES (AND) IRON OXIDES (AND) TITANIUM DIOXIDE	20.00

Procedure:

1. Mix base with other pigments and filler, binder till uniform
2. Fill in mould and stamp to certain shape

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- | | |
|--|--------------------------------|
| (1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials | (2) Whittaker, Clark & Daniels |
| (3) New Phase Technologies | (4) BASF AG |
| (5) Biesterfeld | |

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parateck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.