

FORMULATION EXAMPLE

MC-EL-190703A_C Eyeliner (Dazzling Light Demo Tool - Dark Green)

Ingredients	INCI (US)	[%]
A		
Isododecane	(1) ISODODECANE	46.00
Belsil TMS 803	(1) TRIMETHYLSILOXYSILICATE	20.00
Dub GMS	(2) GLYCERYL STEARATE	3.00
Rheopearl KL2	(3) DEXTRIN PALMITATE	4.00
BENTONE 38VCG	(4) DISTEARDIMONIUM HECTORITE	3.00
Aerosil R202	(5) SILICA DIMETHICONE Silylate	4.00
Beeswax	(1) BEESWAX	2.00
B		
Ronastar® Dazzling Lights	(6) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE IRON OXIDES (AND) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE)	3.00
Ronastar® Diamond Black IQ	(6) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) SILICA (AND) IRON OXIDES	15.00

Procedure:

1. Heat phase A to 90-100°C, mix until homogenous.
2. Cool down until 50°C, add phase B and mix until homogenous.

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- (1) China Chemical Reagent
- (2) Stearinerie Dubois Fils
- (3) Azelis Germany GmbH
- (4) Elementis Specialties
- (5) Evonik Nutrition & Care GmbH
- (6) Merck KGaA, Darmstadt, Germany / EMD Performance Materials

FORMULATION EXAMPLE

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parteck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.

FORMULATION EXAMPLE

MC-EL-190703B_C Eyeliner (Dazzling Light Demo Tool - Green)

Ingredients	INCI (US)	[%]
A		
Isododecane	(1) ISODODECANE	46.00
Belsil TMS 803	(1) TRIMETHYLSILOXYSILICATE	20.00
Dub GMS	(2) GLYCERYL STEARATE	3.00
Rheopearl KL2	(3) DEXTRIN PALMITATE	4.00
BENTONE 38VCG	(4) DISTEARDIMONIUM HECTORITE	3.00
Aerosil R202	(5) SILICA DIMETHICONE Silylate	4.00
Beeswax	(1) BEESWAX	2.00
B		
Ronastar® Dazzling Lights	(6) ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) (AND) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	6.00
Ronastar® Black Allure	(6) IRON OXIDES (AND) SILICA (AND) TITANIUM DIOXIDE (AND) MICA	12.00

Procedure:

1. Heat phase A to 90-100°C, mix until homogenous.
2. Cool down until 50°C, add phase B and mix until homogenous.

Notes:

Stability Test Result : 3 months at 40°C, 4°C, RT, 1 month at 50°C and 12 days cycle (-18°C to 40°C)

Suppliers:

- | | |
|----------------------------------|--|
| (1) China Chemical Reagent | (2) Stearinerie Dubois Fils |
| (3) Azelis Germany GmbH | (4) Elementis Specialties |
| (5) Evonik Nutrition & Care GmbH | (6) Merck KGaA, Darmstadt, Germany / EMD Performance Materials |

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Pardeck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.