

# FORMULATION EXAMPLE

## MDA-P-72-02

### Skin Elixir- turn black into white

### with Ronastar® Diamond Black IQ and Emblica®

#### Ingredients

##### A

Ronastar® Diamond Black IQ  
Glycerol 85%  
Carbopol® ETD 2020

D-Panthenol  
Water, demineralized

##### B

RonaCare® Bisabolol  
Cetiol OE  
Crodamol ISIS-LQ-(MV)  
Tegosoft® DC  
Novemer EC-2 Polymer

##### C

Sodium Hydroxide, 10%

##### D

Water, demineralized  
RonaCare® RenouMer

Emblica®  
Preservatives (q.s.)

#### INCI (US)

#### [%]

(1)	IRON OXIDES (AND) ALUMINA (AND) SILICA	1.50
(1)	GLYCERIN (AND) WATER	3.00
(2)	ACRYLATES/C10-30 ALKYL ACRYLATE CROSSPOLYMER	0.20
(3)	PANTHENOL	0.50
	WATER	79.05
(1)	BISABOLOL	0.25
(3)	DICAPRYLYL ETHER	3.00
(4)	ISOSTEARYL ISOSTEARATE	2.50
(5)	DECYL COCOATE	1.50
(6)	SODIUM ACRYLATES/BEHENETH-25 METHACRYLATE CROSSPOLYMER (AND) HYDROGENATED POLYDECENE (AND) LAURYL GLUCOSIDE	0.50
(1)	WATER (AND) SODIUM HYDROXIDE	0.00
	WATER	5.00
(1)	WATER (AND) POLYSIPHONIA ELONGATA EXTRACT (ALGAE EXTRACT) (AND) SODIUM BENZOATE (AND) CITRIC ACID	2.00
(1)	PHYLLANTHUS EMBLICA FRUIT EXTRACT	1.00
	PRESERVATIVES	0.00

#### Procedure:

Disperse Ronastar® Diamond Black IQ in water of phase A and add Carbopol. Stir, until the gel is homogeneous. Add the other ingredients of phase A. Mix phase B and add to phase A while stirring. Adjust pH value (5.5) with phase C. Incorporate pre dispersed phase D under stirring. Finally, check the pH value again and adjust to 5.3 if necessary.

#### Notes:

Stability: on going

#### Suppliers:

(1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials  
(3) BASF AG  
(5) Evonik Nutrition & Care GmbH

(2) Gattefossé GmbH  
(4) Croda  
(6) Lubrizol

# FORMULATION EXAMPLE

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD 's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Pardeck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.