

Formulation Example

US-P167-18-43 Dew Drop Moisture Balm

T			
ını	ared	IIAn	ITE

Α

RonaCare® Ectoin RonaCare® Allantoin Colorona® Bordeaux Timiron® Halo White

Lecigel

Glycerol 85% Water, demineralized

R

RonaCare® Bisabolol nat. RonaCare® Poppy SE

Preservatives

	INCI (US)	[%]
(1) (1)	ECTOIN ALLANTOIN	0.50 1.00
(1) (1)	IRON OXIDES (AND) MICA SYNTHETIC FLUORPHLOGOPITE (AND) TITANIUM DIOXIDE (AND) TIN OXIDE	0.03 1.00
(2)	SODIUM ACRYLATES COPOLYMER (AND) LECITHIN	1.75
(1)	GLYCERIN (AND) WATER WATER	3.00 ad 100
(1) (1)	BISABOLOL CAPRYLIC/CAPRIC TRIGLYCERIDE (AND) PAPAVER RHOEAS EXTRACT (AND) TOCOPHEROL	0.10 1.00
	PRESERVATIVES	q.s.

Procedure:

This is a cold process procedure.

Combine Phase A ingredients, sprinkling the Lecigel in last with high speed mixing. Allow Lecigel to hydrate until opaque gelled system has formed (about 15-20 minutes). Add Phase B one at a time with high speed mixing until a homogenous emulsion has formed.

Notes

Innovative watery break upon application & yogurt like texture creates a unique experience; a light splash of water rubs down to a soft dryness & impactful, yet subtle silvery sheen. Skin is infused with moisture & left with a soft iridescence... leaving your skin as fresh as early dawn.

pH: 5.9-6.5

Viscosity: Heliopath Spindle TE @ 10 RPM 60 000 mPa*s

Stability: 3 months @ RT, 4°C, 45°C, 3 FT cycles; 1 month @ 50°C

RonaCare® Ectoin is a powerful skincare ingredient that reverses the unsightly effects of daily exposure to environmental pollution and stress, while visibly and measurably reducing the appearance of wrinkles; RonaCare® Allantoin promotes skin rejuvenation; RonaCare® Bisabolol moisturizes; RonaCare® Poppy SE firms and smooths; the addition of Colorona Bordeaux yields a soft berry bulk tone; Timiron Halo White provides a subtle, yet impactful iridescent sheen. \Box

Suppliers:

(1) Merck KGaA, Darmstadt, Germany $\,$ / EMD Performance Materials

(2) Lucas Meyer GmbH & Co. KG

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice.EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parteck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.