

Formulation Example

W 19-21 Face Mask Enchanting Grey

Ingredients	INCI (US)	[%]
A		
RonaFlair® SynMica M	(1) SYNTHETIC FLUORPHLOGOPITE	10.00
RonaFlair® Balance Red	(1) TITANIUM DIOXIDE (AND) MICA (AND) TIN OXIDE	1.00
Ronastar® Black Allure	(1) IRON OXIDES (AND) SILICA (AND) TITANIUM DIOXIDE (AND) MICA	0.20
Ronastar® Red Allure	(1) IRON OXIDES (AND) TITANIUM DIOXIDE (AND) SILICA (AND) MICA	0.08
RonaCare® Ectoin	(1) ECTOIN	1.00
Bole white	(1) KAOLIN	33.00
Water, demineralized	WATER	ad 100
B		
Glycerol, anhydrous	(1) GLYCERIN	5.00
1,2-Propanediol	(1) PROPYLENE GLYCOL	3.00
Tegin® Pellets	(2) GLYCERYL STEARATE SE	4.00
C		
Preservatives	PRESERVATIVES	q.s.
Fragrance	FRAGRANCE	q.s.

Procedure:

Start with the water of phase A and disperse all pigments while stirring, then add Kaolin. Heat phase B to approx. 65°C and add to phase A. If dispersed homogenously, add the ingredients of phase C. The pH-value should be between 6.8-7.0.

Notes:

Another application of our Ronastar® Black Allure and Ronastar® Red Allure. Supported by RonaFlair® SynMica M and RonaFlair® Balance Red a fresh grey Face Mask with a pleasant skin feeling is formed. RonaCare® Ectoin was added as fully natural cell protector and anti-aging ingredient.

Suppliers:

(1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials

(2) Evonik Nutrition & Care GmbH

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice. EMD, EMD Performance Materials, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Partecq, OxyneX, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.