

Formulation Example

MSAS.910.09.09.19 MB 88 Rinse Away Facial Cleansing Powder

| Ingredients | | INCI US | [%] |
|----------------------------|-----|--|-------|
| A | | | |
| RonaCare® Biotin Plus | (1) | UREA (AND) DISODIUM PHOSPHATE (AND) BIOTIN (AND) CITRIC ACID | 0.50 |
| RonaCare® Nicotinamide | (1) | NIACINAMIDE | 1.00 |
| Colorona® SynCopper | (1) | SYNTHETIC FLUORPHLOGOPITE (AND) IRON OXIDES | 1.00 |
| RonaFlair® Fines | (1) | BISMUTH OXYCHLORIDE | 5.00 |
| RonaFlair® Boroneige® SF-9 | (1) | BORON NITRIDE | 15.00 |
| RonaFlair® White Sapphire | (1) | ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE) | 10.00 |
| RonaFlair® Satin | (1) | ILLITE | 19.45 |
| Amisoft® LS-11 | (2) | SODIUM LAUROYL GLUTAMATE | 15.00 |
| Amisoft® MS-11 | (2) | SODIUM MYRISTOYL GLUTAMATE | 15.00 |
| Tapioca Pure | (3) | TAPIOCA STARCH | 15.00 |
| В | | | |
| Oxynex® L-CV Liquid | (1) | ALCOHOL (AND) TOCOPHEROL (AND) CAPRYLIC/CAPRIC TRIGLYCERIDE (AND) ASCORBYL PALMITATE (AND) ASCORBIC ACID (AND) CITRIC ACID | 0.05 |
| Organic Jojoba Oil | (4) | SIMMONDSIA CHINENSIS (JOJOBA) SEED OIL | 3.00 |

Procedure:

Grind the ingredients of phase A until the blend is homogeneous. Then add slowly the premixed phase B and grind until the final product is homogeneous.

Notes:

Appearance: light pink powder

Stability : 3 months at room temperature, 4°C and 45°C

Suppliers:

(1) Merck KGaA, Darmstadt, Germany $\,/\,$ EMD Performance Materials Corp.

(2) Unipex

(3) Masso

(4) IES Labo



Formulation Example

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD Performance Materials Corp. provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD PERFOMANCE MATERIALS CORP. MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD Performance Materials Corp. shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to our complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD Performance Materials Corp. reserves the right to discontinue products without prior notice.

© [2021] Merck KGaA, Darmstadt, Germany and/or its affiliates. EMD Electronics, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parteck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblica are trademarks of Merck KGaA, Darmstadt, Germany or its affiliates. All other trademarks are the property of their respective owners. Detailed information on trademarks is available via publicly assessable recourse.