

Formulation Example

MSAS.953.07.09.20 Natural Body Melting Bar Nourishing & Firming

Ingredients A		INCI EU (INCI US)	[%]
RonaCare® Poppy SE	(1)	CAPRYLIC/CAPRIC TRIGLYCERIDE, PAPAVER RHOEAS EXTRACT, TOCOPHEROL	1.00
RonaCare® Bisabolol nat.	(1)	BISABOLOL	0.50
all-rac-alpha-Tocopherol	(1)	TOCOPHEROL	0.50
В			
DUB® Zenoat	(2)	PROPANEDIOL DICAPRYLATE	8.00
Organic Coconut Oil	(3)	COCOS NUCIFERA OIL	12.95
Deodorized Organic Cocoa Butter	(3)	THEOBROMA CACAO SEED BUTTER (THEOBROMA CACAO (COCOA) SEED BUTTER)	50.00
Lipocire™ A SG	(4)	C10-18 TRIGLYCERIDES	5.00
Cerabeil BIO-D	(5)	CERA ALBA (BEESWAX)	20.00
С			
Colorona® Bordeaux RonaFlair® White Sapphire	(1) (1)	CI 77491 (IRON OXIDES), MICA ALUMINA (OR ALTERNATIVELY: SYNTHETIC SAPPHIRE)	0.05 2.00

Procedure:

Heat the ingredients of phase B at 75°C while mixing. Add phase C and stir until homogeneous. Cool down to 55°C while mixing and add phase A. Then, at 55°C, pour the mixture into molds and put them into a refrigerator for at least 5 hours.

Notes:

Store away from heat

 $\label{lem:appearance:anhydrous light pink solid bar} \end{substitute} Appearance: anhydrous light pink solid bar$

Stability : 3 months at 4°C, room temperature, 45°C and 1 week at 50°C

All our products used are approved by COSMOS or are COSMOS compliant. Other raw materials may be available as COSMOS compliant quality.

According to ISO 16128, 100% of this formulation is from natural origin.

Rub the bar onto your body, spread with your fingers if necessary.

Suppliers:

- (1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials Corp.
- (3) IES Labo
- (5) Baerlocher France SASU

- (2) Stearinerie Dubois Fils
- (4) Gattefossé (Deutschland) GmbH

Surface Solutions



Formulation Example

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. EMD provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. EMD MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. EMD shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of EMD's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to EMD's complete Terms and Conditions of Sale. Prices are subject to change without notice. EMD reserves the right to discontinue products without prior notice.EMD, EMD Electronics, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Candurin, Eusolex, Parteck, Oxynex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblicain are trademarks of Merck KGaA, Darmstadt, Germany. All other trademarks pertain to their proprietors.